## **ROMOLD RENOVATION – AN OVERVIEW**

## MAKE NEW FROM OLD







Lower new base into the chamber



Starting point: corroded concret chamber

Detailed chamber measurements ideally via chamber scan



- easy installation,
- no heavy plant machinery on the building site
- new self-supporting chamber system
- brief water retention
- integrated steps
- load decoupled cover
- long lifetime
- new PE chamber, 100 % corrosion-resistant
- only 1 day installation time, therefore minimal traffic obstruction
- separate, independent chamber system
- no additional renovation



Road restauration



Load decoupled cover



New PE chamber DN 800 in corroded chamber DN 1000





Backfill gap



Filling the gap between DN 800 PE chamber and DN 1000 concrete manhole with filling mortar